Spoke to Matthew — recommended we switch back to recycle mode overnight, and introduce CW in the morning.

1625 Return reactors for start-up mode. Add 131.3 g NaAc to R-1, I-3.

1630 Tietje offsite.

1700 Goh offsite.

David Tsay

4/18/01

800 Tietje / Goh onsite.

810 Getting set to prime metering pumps.

817 MP-1 primed ok — pumping into MX-1
Set stroke / speed @ 30%, 40% respectively
– reset speed @ 50%; stroke @ 30% to generate flows of 1–1.5 g/h

825 MP-2, 4 priming
– prime ok @ 930, but check valve leaks → repair

835 MP-3 priming
MP-3 feeding nutrient solution into MX-1, MX-3 @ max. rate
– again, check valve leaks (take out ball/spring from housing — to disable leaks — SMILE NOT NEEDED)
preferentially metering silica into Tank MX-3 versus MX-1.
– balance feed into MX-1, 3

- Flows balanced at Throttle pump MP-3 back set 3 speed/stroke @ 40%. on

→ Balanced flows into MX-1,3 OK

900 ~~Start pumping from~~ Start MP-4 — pump

910 Start MP-1 - pump OK; check valve OK → no leaks

Pump rate much higher now -
~ 4 gph @ 30% speed/stroke
~ 2 gph @ 20% speed/stroke
~ 1-1.5 gph @ 15% speed/stroke

915 MP-4

Suspect blockage in flow meter
Need to exchange up meter for MX-2

935 Water treatment system started up
Balance flows into MX-1,3

1000 Pumping from Ea2 to Baker Tank → cannot throttle back
Pump P-6 (to reduce outflow through CAC, IX into Baker Tanks)

[illegible] installing new flowmeter on MP-4 discharge line + will wait ~1-2 hrs for glue to dry

[illegible] flows into MX-1,3 ~ OK

PI discharge pressure has dropped

purged discharge line for pump (shut off pump + opened valve + let water drain out); pump disch. & water when re-starting pump; flows into MX-1,3 also have increased [illegible]

[illegible] to LA-1
- want 3 to [illegible]
[illegible]
- [illegible] to [illegible]
[illegible] deaerator

715 gallons — flow fertilizer ~~setup~~ setting @ startup

1035 Turn on bubble diffuser in EQ Tank #1
Turn on heater in T-1

1055 Depart site to PdL parts for plumbing vent for EQ Tank 2, adding valve downstream of pump P-6

1230 Return to site

1235 Turn on MP-4 — pumping into MX-3
MP-4 pumping OK @ install (fructose) setting
- Set speed stroke settings @ 50%
- pumping @ ~5 gph (b)

Adjust speed stroke to 15%. — flow reading is 0

Need to change out pump P-5 (pumping out of EQ Tank 1);
pump pressure is too low to maintain system continuity. Will replace w/ Pump in P-3 position (currently inactive)

Found loc of duct tape in pump formerly in P-5 position — will put in same pump broke in P-5 position

Reinstalled Pump P-5
Checking flow into MX-3 w/ pump off; indicates MP-4 is delivering a small flow into MX-3 ; flowmeter is not working, however, at these low flows (pump settings)
MP-4
@ 25% settings, flow meter reads 3 gph (b) (c)
at any lower pump setting, meter does not record flow

- will keep pump @ 15% settings for other substrate pump (MP-4)

1325 Work on installing valve on outlet side of P-6

1900 Finished installing valve on outlet of P-6 ; Working for glue to dry . . .
Make working on vent piping for EQ Tank #2

1945 Finished installing vent piping for EQ Tank #2

1500 Checked T of water in Tank T-1 - 25°C (77°F)
- Prepare to restart secondary treatment system
- Re-start P-5 → Works much better much better flow rate EQ Tank 2 ; pump down EQ Tank 2 below H-H level throttling back P-5

1530 Turn down settings on nutrient metering (MP-3). Tot flow should be ~ 1 gph (0.67 gph x 0.5)
- Setting @ 20 % stroke
20 % speed

1590 Stopped nutrient addition. Leak in feed line into MX-1.

Tank cap # filled up w/ incoming flow - measured T - 20.

Started to Make Lost. Continued we should start at least (8) T-U tonight, and that it is OK to leave instrument addition offline tonight.

- Turned down settings for MP-4 to ~ 10 %. Speed is stroke
- flow into MX-3 appeared higher than into MX-1.

Cleanup & depart site

Tank 2 Test

#119101

820 Tietje onsite.

830 Equipment checks
P-4 (for MX-3 → R-3)
pumping but discharg. P
very low — need to
inspect

835 Check T in T-1
— 22.4°C
will monitor hourly throughout
day
- turn on heater for T-1;
set thermostat @ 80°F

840 Start-up / prime MP-3 pump —
for nutrient feed
- pump primed OK —
equalize flows OK

855 Discharge P for P-4 ~18
psi after shutting off pump,
opening line + re-starting
Flow incoming to MX 1, 3 @
1.25, 1.4 gpm, respectively

910 Checking flow balancing
between MX-1, 3, about for
pump start could be reversed
slightly in MX-3 — but 2 pumps
start @ pretty similar levels
If both are running on @ almost same
flows through R1, R3 pretty good;
flow into Ex Tank 1 (through
R1, R3) exceeds flow into
MX-1, 3 (2.25 - 2.5 gpm per
tank); flow already pretty
restricted through R1, R3; at
AP high.

925 Pump stop in EQ Tank 1
pretty low — ~ 25 gal remaining
in tank.

Closed valves on outlet of
R-1, R-3 to create back pressure,
reduce flow through — into
EQ Tanks 1.

EQ 2 Pump Through to
Bakker Tanks
P @ outlet of P2 — 23
of GAC — 17
of IX — 8.5

P Q

930 EQ Tank 1 Pumping down too far... PS pumping seeming to bypass float – bumped float switch + pump shut off

1000 Observed similar phenomena w/ EQ Tank 1 – pump running w/ low water level (below float low level) ; again, bumped float switch + pump shut off

1010 Concerns about Nalc feed into MX-3 via MP-4 – very intermittent, appears to have stopped – recheck – OK

1013 Testing nutrient feed rate – preferentially flows into MX-3, and is excessive – reduce pump speed / Stroke to 10% for MP-3 – feed rate still on high side

TIME	TEMP.	COMMENTS
0835	22.4°C	TURNED ON HEAT, SET @ 80°F
0935	22.7°C	COLLECT GW SAMPLE – TEMP. = 20.3°C
1030	23.0°C	COLLECT SAMPLE FROM PILOT – TEMP. 22.3°C
1130	22.3°C	GW PULLED FROM EQ TANK FOR MWCAP
1235	22.9°C	OC PERIOD
1335	23.6°C	GW NOT FLOWING UNTIL FINAL ~10 MIN OF PERIOD
1435	22.7°C	
1530	22.3°C	GW INFLOW DURING PERIOD

1030 Balanced out nutrient feed addition into MX-1, 3

1045 spoke to Mark Lost
- Scientific + Discharge sample Friday / Tuesday, then put system in recycle mode Tues. through the following Monday.
- Monitor heat throughout the day today

1115 Remove can of glue, rag from inside Baker Tank

P-2 (which pumps through R-2) pumpout rate through R-1 pretty close to ^ Incoming flow (~ 2 gpm); MX-1

1140 P-4 pumpout rate through R-3 is slightly higher.

1195 Depart site to pick pants/ lunch.

1230 Return to site.

1250 - 1315 Work on changing out bag filter

P.S

1255 - 1905 Working on replacing N pump start/stop float switch

1910 Cleaned flow totalizer + readings
→ MX-1 : 1291 gal
→ MX-2 : 1345 gal
(compare w/ setting @ 715 startup yesterday ~ 10:30 AM)

1940 Working on adjusting height of float in MX-3 so mixer will always be submerged.

1950 Spoke w/ M. Lost - wants me to pick up COC + revised sampling schedule tomorrow b/f coming to site. Also, I can leave the heat on overnight.

Checking to see if MX-3 is compatible w/ mixer - mixer action may interfere w/ float operation - mixer action hinders operation of float - will keep offline

1515 Checked flow totalizers — based on readings, flow rate has been averaging 1.4 gpm for past hour into the mixing tank.

1525 Checking pumping operation of P-5 w/ newly installed float — pump shuts off OK at low level setting ✓

1545 Checking Pump Cycling For Mixing Tank

Pump down — MX-3

~ 2 minutes

Time to fill to pump start @ 1.3 gpm

~ 7.5 min

$$\frac{7.5 \text{ min} \times 1.3 \frac{\text{gal}}{\text{min}}}{2 \text{ min}} = \text{pumpout rate}$$

$$\approx 4.9 \text{ gpm}$$

1610 Spoke to Lori — confirmed to movements agenda — except that I will be coming to the site first thing tomorrow AM. Also I explained that I believe the lower flow over the last 24-hr period is due to the malfunctioning of pump #P-4 — which triggered a high-high shutoff of P-1.

1620 Depart site.

Paid Trip

4/20/01

745 Tie-in onsite

Equipment check –

– P1 online, but discharge pressure low (~ 5 psi)

Flow into P-1, P-3 MX MX ~ 0.35 – 0.45 gpm

– All other pumps offline

800 – Totalizer readings –

MX-1 – 2023.7

MX-3 – 202.7

Yesterday @ 1400 hrs,

MX-1 rdg – 1291 gal → Δ 732 lbs

MX-2 rdg – 1345 gal → Δ 671 lbs

Flow avg. computes to 0.7 – 0.76 gpm

– Check T in T-1 – 26.4°C (an increase of ~ 4°C)

805 Shut off P-1; open up outfall line / drain; re-start pump → discharge pressure @ 30 psi – OK; open up inlet valves to MX-1, 3 + balance flows

[redacted] MX-1, 3 [redacted]

[redacted]ively

P-3, 4 discharge pressures OK ✓

P-2, 6 discharge pressures OK

Spoke to Mithal yesterday on drive home – told me not to be concerned w/ the flow rate through the bioreactors as that water is cycling through them – that the input they is the flow rate into the mixing tanks – this will equal the overall flow into the bioreactors.

Spoke to Lost and he reading in ~ 10 min + he here 9:30 – 10:00. He asked me to pick up ice before I leave that he gets to the site.

[redacted] as concerned w/ me that [redacted] moving is not needed for [redacted] to take [redacted] but that we are basically

$V_{tank} = \frac{150 \text{ gal}}{7.5} = 20.05 \text{ ft}^3$

$D = 31.62'' \cong 2.64 \text{ ft}$

$H = 4'$

$h - 150 \text{ gal}$

$20.05 \text{ ft}^3 = \frac{\pi \left(2.64 \text{ ft}\right)^2}{4} \times h(\text{ft})$

$h(\text{ft}) \cong 3.66' = 44''$

$h - 140 \text{ gal}$

$18.72 = \frac{\pi (2.64)^2}{4} \times h(\text{ft})$

$h(\text{ft}) \cong 3.42' - 41''$

Tank Volumes – Substrate Tanks

(R-1)
T-1: 41" (compare on Monday)
T-4: 39.5" " "
(R-3)

If we started @ 43" in each tank, then we've depleted only about 7 gal from T-1 & 18 gal from T-4 Cover 24 hr + 14 hr]

– Compare to existing pump settings for MP-1 (R-1), MP-3 (R-3). They are 15 Y. /15 Y. + 15 Y. /10 X – these were based on flow meter reading on AC feed for R-1 (MP-

8:50 – Adjust (Increase) feed rates for MP-1,3
– Adjust settings to 30 Y. /30 Y., respectively (for both pumps)

8:55 – Nutrient Feed Pump – Cannot Determine Pump. Rate – Had Leak + Avg. Pump Did Not Operate Wed. AM – Thur. AM
– current water Level in tank is ~ 112 gallons

Temp. in T-1 – 27.1°C (~80°F)

9:00 Depart site to PU Ice for sampling.

9:30 Return to site.

Temp. @ 27.1°C in T-1; Consider turning off heat

Noticed P5 was still running after water was far below tripped float + low level shut down – Unplugged & locked off pump.

0935 GW begins pumping into T-1.

1000 Tried to connect P7 to receptacle #57 – no juice (check w/ Mike Cobb)

1010 M. Losl onsite. Prepare to collect samples.

1100 Begin collecting "discharge" samples – from Baker Tank.

1130 Finished collecting samples. Took 2 samples going into Baker Tank from port # 15.

1145 Depart site to drop off samples, get lunch.

1305 Return to site

1310 Temp. check
Influent Tank – 25.4°C
R-1 Effl. – 25.1°C

1315 Noticed discharg. P low on R-3, R-4 – Flow rate into mixing tanks only ~ 0.4-0.5 gpm

Shut off pumps, open union valves (R-1), re-start pumps → pressures OK

1320 – Checked level in Feed Tanks 1,4
39.5" – T1
38" – T4
Δ level – 1.5" / 5 hrs
5 gal/5 hrs – 1 gph
– therefore these flow settings seem to be working well

1325 Increase feed rate of MP-3 – nutrient feed pump (set @ 30 Y., 30 Y.)
level ~ 112 gallons

1335 Shut off mx-1 per Losl's instruction – due to too much agitation.
Need to install inlet pipes in mixing Tanks to direct flow below water surface.

1340 Taking T reading in T-1 → 25.9°C
Losl / shut off heat tape.
Will want to re-start Monday am.

1400 Spoke w/ Charlie Galloway — Pumps are heating up, causing bubbles to form, which creates cavitation + Pressure switch on motor causes loss of pressure — turns motor off for

- Part in bypass line w/ PRV that will relieve discharge P. — vent (connect to tank)
- operation @ higher flows will help eliminate problem

1900 Plant on EQ Tank 1 still getting hung up + not shutting pump off @ low level

- May want to consider opening valves 100% on inlet to bioreactors

→ Trying this
P on ~~disch~~ discharg. of P-2 ~ 18 psi ; on outlet of P-1 0 psi
~~~~ ~~20 psi — 0 psi for P-4~~
Q into the EQ tank is slightly higher.

1415 S/w Vitthal about cavitation of the centrifugal pumps, particularly P-1. He said I can put in a bypass line (using smaller D pipe) + direct it from the pump discharge into the ~~tank~~ tank T-1 (this way I can recycle some of the flow, which will help reduce the back pressure on the pump). For P-2,4, for now it is satisfactory to ~~throttle~~ modulate the throttling of flow through the bioreactors (by opening the valves on the inlet + discharge 100%.)

- Plumbing — 1/2" pipe — 20' section
  1/2" 90's — 4-6
  1 1/2" 45's — 2-4

1445 Collected samples for PCR analysis from R1 eff, R5 effl. Put in refrigerator (freezer section).

1500 Clean up / depart site.

~~P-1 Inlet~~
~~~~

4/23/01

820 Metje onsite.

830 Equipment Check

R1 on but low discing. P due to cavitation (~ 8 psi)
Flow into = MX 1,3 0.42 gpm each.

Total Flow, FM-1 3091.2 gal
FM-3 3118.6

P-3 running but ~2 psi discharge pressure (due to cavitation)

P-3 online w/ ~0 psi (due to cavitation)

Levels in substrate feed tanks, nutrient feed tank

Subst. v. low

(Tank 1) S#1 (R-1) — approx. 3" water
(Tank 4) S#2 (R-3) — approx. 3" solution
Subst. (Tank 3) Nutrient (R-1,3) ↓ 5.75" solution

Checking H_2O temp. in T-1 - 20.0°C

Δ water processed - for. PM to Mon. AM

R-1 system — 1067.5 gal
R-2 system — 1096.9 gal
Time: 72.5 hours
∴ Avg. Flow ~ 0.25 gpm / reactor

Nutrient / Substrate Tanks

Tank #1 — Δh = 39.5 - 3 = 36.5"
in 67.5 h
→ 1.03 gph
(24 gal)

Tank #4 — Δh = 38 - 5.75 = 32.25"
in 67.5 h
→ 1.63 gph
(10 gal)

Nutrient Tank (#3) — 112 gal - 12 gal
67.5 h
= Should be ~0.7 gph = 1.48 gph

Turn down speed / stroke settings by ~ 1/3 to 20% / 20% for ST-1 (R-1)
20% / 20% for ~~ST-2~~ NT, and 20% / 20% for ST-2 (R-3)

910 Performed pumps P1, P2 P5 — discharge pressures OK for each

— Accidentally reset FM-3 totalizer to 0.0 gal

920 Spoke to Lori — told me it would be a priority today to install the inlet pipes in MK-1, MK-3.

925 Noticed some bridging in R-2; will need to keep an eye on this today.

930 — Filling SF-1, 3, Nutrient Supply Tanks to 150 gal w/ tap water (cannot circulate water through carbon)

1010 Spoke w/ M. Lori — he explained we have a project progress mtg. tomorrow from 9 AM to 3:30 PM during which we will discuss the project progress, do a site walk, + discuss the system enhancements.

1020 Added 2442 g $(NH_4)_2HPO_4$ to 150 gal water to make up nutrient feed tank

1025 Begin measuring / adding 9003.7 g NaNO3 to ST-1

— weighing out 100 g increments — IIII IIII IIII IIII IIII IIII IIII IIII

— 1 @ 103.7 g

1115 Begin measuring / adding 9003.7 g NaNO3 to ST-3.

— weighing out 100 g increments — IIII IIII IIII IIII IIII IIII

∴ Realized I had an 8 kg container initially, less 3.7 g = flakes, I could add the rest of the contents + then 2x 3.7 g from a new bag.

— 8 kg NaNO3 supply remaining; will need additional by next Monday

1210 Depart site for lunch + to pick up PVC fittings / pipe.

1340 Return to site.

1345 - Shut off P-1; Begin installation of inlet piping for MX-1, 3
- Shut off MP-1, 3, 4

1355 Noted P-5 seems to be cavitating again - shut it off for interim repairs.

1530 Restart P-1 - OK
MP-1, 3, 4 - OK

Turn on P-5 - OK

1600 T in T-1 - 20.7°C

1610 Checked fluid levels in substrate injection tanks -
ST-1 - 43"
ST-2 - 94"
Nutrient - 42.5"

1615 Tie off sites.

Pond Tech

4/24/01

745 Tietje onsite. M. Losi already onsite, working on prepping to sample.

Equipment check

P-1 offline due to H-H in MX-1; P-1 is running but dischg. P is ∅ (pump cavitating)

755 Shut off P-2, opened up union / closed union, re-started P-2 — dischg. P ok

P-1 back online — P low (~11 psi) + flow into MX-1,3 low (~0.5 gpm/each)

- Shut off P-1; opened up union; re-started P-1, opened throttle valves — P ok; adjusted flow into MX-1,3 to ~1.0 gpm/ea

Totalizer readings

- MX-1 : 3810 (compare to 3091)
- MX-3 : 3764 (compare to 3118)

@ 0830 yesterday

$Q_1 = \frac{3810 - 3091}{24 \times 60} = 0.5$ gpm

$Q_3 = 0.45$ gpm

- Check levels in substrate / Nutrient Feed Tanks

- ST-1 - 42"
- ST-2 - 43"
- NT - 40.75" - 148 gal
- last readings were taken @ 1610 yesterday / ~16 h ago

Δ h, ST-1 = 1" — ~3.4 gal

h, ST-2 = 1" — ~3.4 gal

h, NT = 1.75" — ~6 gal

3.4 gal/16 h — 0.21 gph

6 gal/16 h — 0.375 gph

- Check pumping on metering pumps
- Turn up settings to ~25 % stroke/spd.

845 Finish changing out bag filter. Changed out filter collected more solids than initial filter changed out.

- Checking influent T - 20.1°C

- Noticed small leak developing in R-1

910 Noticed problem in MX-1 when float does not shut off pump @ pre-set level, flow into tank is not beneath H_2O surface.

930 Depart site to meet w/ R. Zurowski, E. Nyer.

1205 Return to site.

1230 Shut off flow through R-1 due to bulging (health & safety issue). Flow continuing through R-3 @ 1 gpm avg.

1300 ~~Restart~~ feed concentrations for MP-3 [$(NH_4)_2PO_4$] & MP-4 (NaAc) into MX-3.

- Desire 25 mg/L [Na^Ac] in final flow — ∴ cut flow rate in half to ~ 31.5 mL/min feed rate

- used cup & stopwatch to confirm flow is ~35 mL/min @ pump settings 25%. /25%., for MP-4

- Adjust feed of $(NH_4)_2PO_4$ due to reduced flow w/ only one reactor running. New feed rate should be ~ 21 mL/min (1/5 gph). Confirmed MP-4 flow is 20-21 mL/min into MX-3 w/ cup/stopwatch @ ~ 15/20 %.)

1340 Estimating pump rate for P-4

Vol. fill — MX-3 (@ time pump starts)

Vol. empty — MX-3

Δh = 8 in.

$V = \pi r^2 h$

$V = \frac{\pi d^2}{4} \times h$

$= \pi \frac{(20.06)^2}{12} \times h$ (ft)

$= 2.2 \times h$ (ft)

$= 1.46$ ft^3

~11 gal

- timed pump-down cycle - 50 sec

→ 13.2 gpm flow

07:30

1400 Add dye (~1 mL) (right after completing pump cycle)

1405 - Begin closing down back half of system; also testing P-6 / bag filter for leakage

- Shut off MP-3, 4

1410 Shut off P-6 - bag filter leaked initially, then OK

1419 Pump cycle started - assume start of residence time (dye did not enter reactor until start of pump cycle).

1430 - Hint of dye detected in Eq T. #1 (will confirm on next cycle)

- Shut off MW-7 pump

1440 Untreated water inside Eq-Tank is colored - confirm breakthrough of dye

1445 Shut off P-1 (feed into MW-3. Will re-start P-1 tomorrow AM, and feed Ac @ 1/2 rate, then sample for NO_3^-, Ac, Cells on the influent/effluent of the reactor @ day's end.

Lost offsite.

1500 Tested offsite.

Picture

4/25/01

840 Tietje onsite. System is down.

850 - Turn on P-1 reconnect (electrical for) MMX-1 pump
- Reconnected (electrical) for P-5/P-6 and MP-3, 4

910 - will keep MP-3,4 settings the same as yesterday in order to reduce the feed by 50 %. (MP-4)
MP-3 : 15%. (Stroke) ; 20 %. (Speed)
MP-4 : 20 %. 120 %.

- Verify ~~same~~ feed rates of MP-3, 4
① Shut off MP-4, test MP-3
- collected 18 ml 160 sec [desire 20-21 ml/min √
② Shut off MP-3, test MP-4
- collected 31 ml 160 sec [
desire 31 ml/min √)

945 Temp in T-1 - 21.3°C

Begin working on plumbing bypass for MX-1

1115 Finish plumbing bypass for MX-1

1125 SW Withdrawal - told me
① I need to focus on plumbing the bypass loops for P-1-4,
② I need to check the rentals vs. the P.O.'s vs. the budget
ASAP ; ③ that they found vessels that can be rented for $ 200 /mo. that are rated for 75 psi & can be equipped w/ internals as needed

- Begin working on bypass piping for MX-2

1130 Turned on aquarium pump in Eq Tank 1

1200 Taking equipment inventory -
Need to buy PVC fittings to plumb bypasses
- 2" x 1" reducer, SOC, 1
- 1½" male Adapters, 2
- 1½" PVC ball valve, FT, 2
- 1½ PVC check valve, FT, 2

- 3/4" male Adapter 2
- 3/4" x 1" BSC reducer 1
- teflon tape
- primer
- vinyl gloves

1215 Depart site to PK PVC fittings & lunch

1300 Departed Home Depot

1345 Picked up ice for sampling.

1900 Back onsite.

1405 P1 dischg. P low — note flow into MX-1 is approx. 0.6 gpm; Resume P1

1410 Resume working on plumbing for MX-2

1500 ☆ Noticed nutrient pump offline - turned on nutrients pump (MP-3)

1510 Begin preparation for sampling

1520 Slw Lost + confirmed days sampling schedule=

SP# 1 Cl^-, NO_3^-
SP# 7 TOC, Ac
SP# 10 Cl^-, TOC, Ac, NO_3^-

- Use TOC bottle, 125 mL, as substitute for 40 mL 2nd acetate bottle
- Ephram will transfer contents into a new container @ the lab.

1600-1615 Collecting samples for various analyses (Cl^-, NO_3^-, Ac, TOC)

- For SP#7, used 1/4" tubing which had some residual food coloring (cleared out b4 sampling).

1620 Turned off MP-3, 4, P-1, P-4 and MW-7 pumps.

1625 Depart site

Pond Tests =

4/26/01

900 Tietje onsite. Stopped @ Home Depot en route to site to pu PVC fittings.

- Last night, pu 30 x 40 mm Acetate bottles from MWW laboratories.
- Stw make Con ensuite to site exhaust plumbing bypass to T-1 — he said it is OK to bring line in to inlet w/ monitoring GW, as long as I have backflow protection

915 Re-start system w/ P-3 operating only (note: did not plug pump in MW-7 — enough water in EQ Tank run w/ this)

- Manually adjust feed from MW-4 (Ac feed) — want to reduce feed rate again to 31.5/2 mL/min (15.75)
- Adjust speed 15 min to 15%. each → feed rate too low — increase to ~ 20%. 1204.

— feed rate is ~ 13 mL/min

— increased speed to 22%.

— feed rate ~ 18.5 mL/min

— reduce speed back to 20%.

940 → feed rate ~ 66.5 mL/min — OK

— turn on MW-3 (upstream feed)

— keep on same setting as yesterday

945 Check flow rate into MX-1 → 1.2 gpm

1000 Stw Lost — told me to operate the system today of half the Ac. feed, as we had discussed yesterday, and depending on these results may opt to run during the day time next week.

1005 — continue working on plumbing bypass line for MX-2

— Adjust flow into MX-1 to ~ 1.50 gpm

1045 Finished P-3, MX-2 bypass line

→ 1120 working on reviewing notes from mtg. earlier this week.

★ Noticed on P-1 pump cycle, ΔP through R-3 is early ~ 12 psi vs. ~ 20 psi when initially opening up valve @ inlet to R-3 (not throttling the flow)

1200 N — Begin working on plumbing bypass for P-1.

1215 — Depart site to pick up lunch / ice / plumbing parts for bypass

1300 — Return to site.

1310 — P1 offline — pump shut off due to float low level — will bypass float + run pump as necessary

1315-35 — Break for lunch

1335 — Resume working on bypass piping for P-1

1950 — Check FM totalizer readings

FM-1: 3963 gal

FM-2: 4030 gal

1515 — Spoke w/ Mark Losi

- recd results from Tuesday's sampling - which indicated breakthrough from both reactors.
- told me to sample today the same as yesterday, w/ influent NO_3-/CCl_4-, R-influent TOC + Acetate and NO_3-/CCl_4-/TOC/Acetate in R-effluent.

1525 — Begin preparation for sampling.

1550 — Slow withdrawal and confirmed that I will shut down the system today after sampling; the aerator for the Buffer Tank will be left online.

1615 — Complete sampling. Shut down PBR R-1. Clean up.

5/17/01

1100 Tietje onsite. HazPak, Inc. already onsite & working since ~ 10 AM - called @ 10:30 AM to confirm).

1100-1130 Drop off drums at site, 11 closed top 5 open top

1140 Depart site to PU hose / lunch.

1250 Return to site.

1300 Set up pump / hose to transfer NaAc & nutrient solutions into closed top drums

1315 Begin transferring solution from substrate tanks into drums.

1410 Finished pumping out NaAc soln. into drums. Left ~ 20 gal in 2nd tank for sampling. Will transfer into 5th drum, which is ~ ½ full.

1420 - to 1455 Pump out nutrient soln into closed top drums. Leave about 10 gal inside tanks for sampling & diluted w/ ~ 15 gal tap water (due to crystals on bottom of tank)

1455 Manually pump ~ 50 gal GW in Eq Tank 1, ~ 40 gal GW in Eq Tank 2 through secondary treatments into Baker Tank.

Added tap water into Eq Tank 1 to remove (wash out) some bacterial growth on sides + bot of tank; likewise for Eq Tank 2...

1500 JE repr. stops by site to inform me he will be shutting down power for ~ 15 - 30 minutes.

1600 Completed work on transferring NaAc in unused "bioreactor" drum (only used w/ tapwater) into open top drums. Cleaned out bioreactor drum & portable-

- will dispose as non-RCRA
" empty "

1600

- slw Vitthal - confirmed I will continue be onsite tomorrow Am to " work on the waste disposal.

1620 clean up & depart site.

D. Tech



INDEX OF CURVE AND REDUCTION TABLES

Table I—SLOPE STAKE

Table II—STADIA CORRECTION AND HORIZONTAL DISTANCES

Table III—TRIGONOMETRIC FORMULAE

Table IV—NATURAL TRIGONOMETRICAL FUNCTIONS

CURVE FORMULAE

Table V—TANGENTS AND EXTERNALS TO A 1° CURVE

USEFUL RELATIONS

Table VI—INCHES TO DECIMALS OF A FOOT

Table VII—MINUTES IN DECIMALS OF A DEGREE

Table VIII—MIDDLE ORDINATES OF RAILS

Table IX—SHORT RADIUS CURVES

Table X—RODS IN FEET, 10THS AND 100THS OF FEET

Table XI—LINKS IN FEET, 10THS AND 100THS OF FEET

5/18/01

JPL PBR

835 Tietje onsite.

850 Set up pump to transfer water inside inocula tanks (3) into drum.

855 - 900 Transferring water inside inocula tanks into drum

Add fresh water to break up some of the slimy growth on tank walls

There is a layer of "sludge" on bottom of inocula tanks

950 Begin working on 4 bioreactors — separating liquid & solid

— Cake has consistency of wet sand

1350 Completed waste segragation for R-1 & R-2

2 Empty Drums

2 Drums w/ D.E. & Internal Piping

2 Drums w/ Wastewater

☆ will need 1-2 additional closed top drums to complete 2 remaining waste drums.

1410 Offsite